Sliding doors fino (Suspension system)
single-leaf sliding in the wall
1 track (Ceiling installation)







inova®
The Room System

Calculation of leaves:
Clear width + 12 mm = Overall frame width
Clear height - 60 mm = Overall frame height

Calculation of track:
Leaf width x 2 = Track length

A. Track
B. Carriage
C. Track pelmet
D. Vertical profile
E. Receiving plate
G. Distance to floor
H. Floor guide
K. Dog

Sliding doors fino (Suspension system)
single-leaf sliding in front of the wall
1 track (Wall installation)







inova®
The Room System

Calculation of leaves:
Clear width + 25 mm = Overall frame width
Clear height + 2 mm = Overall frame height

Calculation of track:
Leaf width x 2 + 50 mm = Track length

A. Track
B. Carriage
C. Track pelmet
D. Vertical profile
E. Receiving plate
G. Distance to floor
H. Floor guide
K. Dog

Sliding doors fino (Suspension system)
single-leaf sliding under the ceiling

1 track (Ceiling installation)







inova®
The Room System

Calculation of leaves:
Clear width + 25 mm = Overall frame width
Clear height - 60 mm = Overall frame height

Calculation of track:
Leaf width x 2 + 50 mm = Track length

A. Track
B. Carriage
C. Track pelmet
D. Vertical profile
E. Receiving plate
G. Distance to floor
H. Floor guide
K. Dog

Sliding doors fino (Suspension system)
double-leaf sliding in front of the wall
1 track (Wall installation)







inova®
The Room System

Calculation of leaves:
Clear width + 21 mm : 2 = Overall frame width
Clear height + 2 mm = Overall frame height

Calculation of track:
Leaf width x 4 + 50 mm = Track length

A. Track
B. Carriage
C. Track pelmet
D. Vertical profile
E. Receiving plate
G. Distance to floor
H. Floor guide
K. Dog

Sliding doors fino (Suspension system)
double-leaf sliding in the wall
1 track (Ceiling installation)









inova®
The Room System

Calculation of leaves:
Clear width + 21 mm : 2 = Overall frame width
Clear height - 60 mm = Overall frame height

Calculation of track:
Leaf width x 4 = Track length

A. Track
B. Carriage
C. Track pelmet
D. Vertical profile
E. Receiving plate
G. Distance to floor
H. Floor guide
K. Dog

Sliding doors fino (Suspension system)
double-leaf sliding between walls
2 tracks (Ceiling installation)







inova®
The Room System

Calculation of leaves:
Clear width + 18 mm : 2 = Overall frame width
Clear height - 60 mm = Overall frame height

Calculation of track: Lichte
Breite = Track length

A. Track
B. Carriage
C. Track pelmet
D. Vertical profile
E. Receiving plate
G. Distance to floor
H. Floor guide
K. Dog

Sliding doors fino (Suspension system)
double-leaf sliding under the ceiling
1 track (Ceiling installation)







inova®
The Room System

Calculation of leaves:
Clear width + 21 mm : 2 = Overall frame width
Clear height - 60 mm = Overall frame height

Calculation of track:
Leaf width x 4 + 50 mm = Track length

A. Track
B. Carriage
C. Track pelmet
D. Vertical profile
E. Receiving plate
G. Distance to floor
H. Floor guide
K. Dog

Sliding doors fino (Suspension system)
three-leaf sliding between walls
2 tracks (Ceiling installation)





Floor guide



inova®
The Room System

Calculation of leaves:
Clear width + 44 mm : 3 = = Overall frame width
Clear height - 60 mm = Overall frame height

Calculation of track: Lichte
Breite = Track length

A. Track
B. Carriage
C. Track pelmet
D. Vertical profile
E. Receiving plate
G. Distance to floor
H. Floor guide
K. Dog

Sliding doors fino (Suspension system)
three-leaf sliding between walls
3 tracks (Ceiling installation)







inova®
The Room System

Calculation of leaves:
Clear width + 44 mm : 3 = Overall frame width
Clear height - 60 mm = Overall frame height

Calculation of track: Lichte
Breite = Track length

A. Track
B. Carriage
C. Track pelmet
D. Vertical profile
E. Receiving plate
G. Distance to floor
H. Floor guide
K. Dog

Sliding doors fino (Suspension system)
three-leaf sliding under the ceiling
2 tracks (Ceiling installation)







inova®
The Room System

Calculation of leaves:
Clear width + 77 mm : 3 = Overall frame width
Clear height - 60 mm = Overall frame height

Calculation of track:
Rahmenaußenmaß x 5 = Track length

A. Track
B. Carriage
C. Track pelmet
D. Vertical profile
E. Receiving plate
G. Distance to floor
H. Floor guide
K. Dog

Sliding doors fino (Suspension system)
four-leaf sliding between walls
2 tracks (Ceiling installation)





B = Floor guide



inova®
The Room System

Calculation of leaves:
Clear width + 40 mm : 4 = Overall frame width
Clear height - 60 mm = Overall frame height

Calculation of track: Lichte
Breite = Track length

A. Track
B. Carriage
C. Track pelmet
D. Vertical profile
E. Receiving plate
G. Distance to floor
H. Floor guide
K. Dog

Sliding doors fino (Suspension system)
four-leaf sliding under the ceiling
2 tracks (Ceiling installation)







inova®
The Room System

Calculation of leaves:
Clear width + 73 mm : 4 = Overall frame width
Clear height - 60 mm = Overall frame height

Calculation of track:
Rahmenaußenmaß x 6 = Track length

A. Track
B. Carriage
C. Track pelmet
D. Vertical profile
E. Receiving plate
G. Distance to floor
H. Floor guide
K. Dog